

## Self-Adhesive Woven Textile & Self-Adhesive Glittered Wallpaper

### Preparation

#### Tools you will need

Measuring tape, plumbline, pencil, a sharp utility knife, straight edge, step ladder tall enough to reach the top of your wall safely, application squeegee.

To ensure maximum adhesion of your personalised wallpaper, priming your wall surfaces is recommended in the following instances:

- An existing paint job containing Teflon and other washable surfaces
- An old, damaged, or flaking existing paint job
- Wall surfaces with uneven surfaces, including cracks and panelling

Existing wallpaper should be removed from wall surface prior to the installation of new personalised wallpaper.

Clear all furniture and other obstructions from your work area.

Using a drop sheet to protect flooring is highly recommended.

**Note:** Your wall surfaces should be clean, smooth, dry and free of debris.

### Installation

For a premium result, professional installation is recommended.

For DIY installation, two people are recommended. Please read all instructions, prior to installing.

Use a plumbline to hang your first panel of wallpaper in order to get it perfectly straight. At a point close to the ceiling, measure 500mm from the left hand edge/corner of the wall where you are going to hang the first panel (in the direction you are going). Put a mark close to the ceiling at this point. This is where you will hang your plumbline from. Mark down the plumb line approximately every 300 to 400 mm. This will provide you with a good vertical line to hang your first wallpaper panel to. Note that the first panel will have additional 50.8mm overhand on the left and top to enable a neat and flush cut on the edge/corner of your wall.

1. Working left to right, starting with panel 1, peel and fold back approximately 30cm of the backing liner. This is your leading edge.
2. Using a step ladder, apply the leading edge of panel 1 starting at the top left of your wall or surface. Allow 50.8mm overhang at the top of the wall, remembering that there is also an overhang of 50.8mm extra on the left edge/corner (only on the first panel, and on the right side of the last panel).
3. Using a clean application squeegee, gently apply the panel to the wall, smoothing it out in a zig-zagging downwards motion, removing any bubbles as you go. Repeat this process for the remaining panels.

**Note:** There will be a 10mm overlap for all subsequent panels. Ensure the image on the overlapping section lines up with the previous panel.

**Tip:** To remove large bubbles, carefully remove the affected section and reapply.

4. Using a straightedge as a guide and a sharp blade, carefully trim off excess wallpaper.

**Tip:** The blade must be sharp to prevent tearing.

## Removal

To remove self-adhesive wallpaper, carefully lift any corner and peel until completely removed from wall surface.

**Note:** Paint stripping may occur when removing self-adhesive wallpapers, post 6 months installation.

**Tip:** To remove excess residue, citrus based cleaning agents are recommended. Follow the directions on the packaging.

*“Do-It-Yourself Personalised Wallpaper Projects are “at your own risk”. As with any DIY project, unfamiliarity with the tools and application process can be dangerous.*

*If you are at all uncomfortable or inexperienced with applying wallpaper, please reconsider completing the job yourself and seek professional installation.*

*It is possible to damage your wall surface. Officeworks will not be held responsible for any damages due to the misuse of this product.*

*Always read instructions prior to attempting installation.”*