








# Stratus Chair

## Assembly Instructions

Parts Listing				
Castors	5		Seat Cushion	1
Star Base	1	Mechanism	1	
Gas-lift mechanism	1	Backrest Cushion	1	

		
<b>Step 1:</b> Push each of the 5 castors firmly into the chair base.	<b>Step 2:</b> Insert the gas-lift mechanism into the chair base. Slide the telescopic cover over the gas-lift.	
		
<b>Step 4:</b> Insert the back in the seat mechanism slot and tighten with the knurled knob provided	<b>Step 5:</b> Insert top of the gas-lift column into the seat mechanism. Turn the chair upright and carefully sit on chair. If stable, sit down firmly a couple of times to ensure all parts are firmly in place.	<b>Your new Stratus chair is now assembled and ready for use.</b>

**Care & Maintenance:** Your new Stratus Chair will serve you well, given a little care and ongoing maintenance. Periodically check that all screws/bolts are tight, as constant chair use can cause them to loosen. For any spills, immediately wipe off using a damp sponge or cloth.



Do you require assistance with the assembly of this quality product?  
For a free, no obligation quotation call  
**FREECALL 1300 799 289**